A/C COMPRESSOR MOUNTING BRACKET

40-108R (Lower Passenger Side) Chevrolet Big Block V-8 with Short Water Pump Requires remote fuel pump

TIGHTENING.

pump pulleys.

3/8" X 5" Bolt Original Fuel Pump Mounting Holes **NOTE: REMOVE** 1-5/16" Spacer Compresso **FUEL PUMP** 3/8" X 5" Bolt START ALL MOUNTING BOLTS BEFORE 1-11/16" Spacer We use a belt length of 46-1/2 to 47 inches Flat Washer with this mount on installations in our shop. 7/16" X 1" Bolt However length of the belt may vary with the diameter of your crankshaft and water 3/8" X 1" Bolt 3/8" Nylock Nut 3/8" Nylock Nut Compressor www.oldairproducts.com

1201 Forum Way South - Fort Worth, TX 76140 (817) 531-2665 - FAX (817) 531-3257

MAKE SURE THIS BRACKET FITS YOUR APPLICATION BEFORE PLATING OR PAINTING. ALTERED BRACKETS CANNOT BE RETURNED FOR REFUND.