

alternator before tightening.

(We use a belt length of 52-53" with this mount on When installing the mount, start all bolts and mount the installations in our shop. However; this can vary with the diameter of your pulleys.

As with any part of this nature, make sure it fits your application before painting or plating. Parts that have been painted, plated or modified may not be returned.